

 **PRECISIONPRO®**

TITAN

SLOPE RANGEFINDER



PRODUCT MANUAL

TITAN




TABLE OF CONTENTS

- **Product Overview**
 - **Main Parts**
 - **LCD**
 - **Charge Port**
 - **Yards to Meters**
- **Charging Your Titan Elite**
- **Using Your Titan Elite**
 - **Point and Shoot Function**
 - **Visual Target Lock Function**

PRODUCT OVERVIEW

Main Parts

1. Power/Laser Button
2. Mode Button
3. Slope Switch
4. Adjustable Eye Piece
5. Magnetic Grip
6. Charge Port Cover




PRODUCT OVERVIEW

LCD

Laser Screen:


1. Aiming Reticle
2. Visual Target Lock Rings
3. Non-Slope Distance
4. Slope Adjusted Distance
5. Yards/Meters Indicator
6. Battery Level Indicator
7. Slope Indicator



PRODUCT OVERVIEW

Charge Port


1. Charge Status Light
2. USB-C Charge Port
3. Serial Number Sticker




PRODUCT OVERVIEW

Changing from Yards to Meters / Meters to Yards

1. Make sure the LCD is off.
2. Hold the Laser Button and Mode Button for 5 seconds.



3. You will see the Y change to an M or the M change to a Y.




CHARGING YOUR TITAN

USB-C

Charge Status Light:

- Flashing when charging
- Solid when fully charged




TITAN




USING YOUR TITAN


Point and Shoot Function



1. Turn LCD On by pressing the Power/Laser Button one time.



2. Position the Aiming Reticle over your intended target.




3. Press and release the Laser Button to shoot the distance to your target. The Center Circle will appear, distances will be displayed, and you will receive a pulse vibration, indicating that you have locked onto a target.


You can use this function to shoot the lips of bunkers, edges of water, or trees at the dog leg as well!

USING YOUR TITAN


Visual Target Lock Function



1. When the LCD is on, position the Aiming Reticle to either side of your intended target. In this case, we are aiming for the flag!



2. Press and hold the Laser Button to receive the distance to the background. During this time, the center circle will flash as the Titan waits for you to move the Aiming Reticle over the flag. Keep holding the Laser Button!



3. As you are holding the Laser Button, move the Aiming Reticle over the flag. The Titan will recognize your target and provide a pulse vibration along with a visual ripple effect around the Aiming Reticle. This indicates that you have successfully locked onto the flag!



ESCAPE THE ORDINARY

TITAN



 **PRECISIONPRO[®]**

ESCAPE THE ORDINARY